

MOUNTING LOCATION:

Right side of climate control CR

TOOLS REQUIRED:

T20 Torx wrench

PARTS INCLUDED:

- (1) (S7-1445-1) Mount
- (1) Spacer (S7-1445-2)

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS**

PART#: 75141-299

MFG: FREIGHTLINER

MODELS & YEARS:

**Conventional Cab 1989-2010 (FLD)
Classic 2000-2010, ClassicXL 2000-2010**

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 Remove the (2) T-20 Torx screws to the right side of the climate control. Set screws aside.

STEP #2 With your hands, pull on the right side of the panel that surrounds the climate control just enough to slide the InDash Mount under the panel. Place InDash under the panel and place the spacer (Classic only) over the InDash mounting holes. Align all the holes and place the panel in place. Install the factory screws back in place.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Classic Final Install Showing Location



ClassicXL Final Install Showing Location



04-23-13