

INDASH by PANAVISE®

I-75105-502

Page 1 of 1

MOUNTING LOCATION:

Below right air vent

TOOLS REQUIRED:

Hook tool

Phillips screwdriver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: **75105-502**

MFG: **DODGE**

MODELS & YEARS:

Ram Pickup 1500 2002-2005

Ram Pickup 2500 2003-2005

Ram Pickup 3500 2003-2005

(New Body Style)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Phillips screwdriver, remove the screw located by the purse/bag hook to the left of the glove box and below the right center air vent. Insert hook tool into the lower right edge of the large bezel to release (1) clip. Continue to work all the way around the bezel which includes the (2) center air vents, climate control, and accessory controls. Disconnect (2) climate control plugs, lighter plug, and any other plugs necessary to get at the screws.

STEP #2: Pull off the bezel enough to get to the screws holding the blank plate on that is under the right center air vent. Remove the (3) screws holding this plate on. Install the phone holder prior to installing this mount.

STEP #3: Place the InDash over the pin and screw hole on the left of this plate. Replace the plate and the (3) screws removed.

STEP #4: Reinstall the bezel and screw in the screw by the bag holder.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Plate mount is installed through



Installed InDash through opening



Finished Install Picture



10-24-04