IIDASH PANAVISE®

I-75141-404

Page 1 of 1

MOUNTING LOCATION:
Left side of climate control
TOOLS REQUIRED:
T-25 Torx Driver
PARTS INCLUDED:
(1) \$7-1775 mount

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75141-404**MFG: **FREIGHTLINER**MODELS & YEARS:
Business Class (M2), 2004-2017

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With the T-25 Torx driver, remove the (4) screws that hold the clomate controls in place.

STEP #2: Lift up on the leftt side of the climate control. Place the InDash by PanaVise over the screw holes, under the climate controls. Reinstall the (4) screws.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Prototype installed showing location only

