

INDASH ^{by} PANAVISE®

75105-513

Page 1 of 1

MOUNTING LOCATION:
Left side of Cubby by CC ML

TOOLS REQUIRED:

Phillips Screwdriver

PARTS INCLUDED:

(1)S7-2057, (1)S7-1932(75001)

(4)-A-#8x9/16" Needle Pt Screw

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

PART#: 75105-513

MFG: DODGE /RAM

MODELS & YEARS:

RAM 1500-5500 2013-2018

(W/ Open Cubby by Climate Control)

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Remove the right side of climate control cubby mat, by lifting up to release (2) rubber studs. Set aside

STEP #2: Place InDash by PanaVise Mount bottom on left side of cubby with L-part of bracket going to the right at the back of cubby above dividing line. Install the (4) screws supplied in the (4) Mounting holes. (2) at the back and (2) just inside the cubby. *Make sure the mount is flush to the side of the cubby prior to installing the back (2) screws.* Carefully replace the rubber cubby mat.

STEP #3: Install the Top part of the InDash by PanaVise Mount (75001) with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Bottom part of mount in place showing screw locations (4)



Showing mount in place and holes for mout top installation



InDash installed showing location



11-29-17