IIDASH PANAMSE®

MOUNTING LOCATION:

Right or Left side of display JPRL

TOOLS REQUIRED:

Hook Tool Flat Bezel Tool

9/32"(7mm) Socket Driver

PARTS INCLUDED:

(1)s72064&(1)S71932(75001) 2 - (0) 8/32 Acorn Nuts

CELL PHONE & MEDIA MOUNT Installation Instructions

> PART#:75122-214 MFG:JEEP / DODGE **MODELS & YEARS:**

Grand Cherokee 2014-17 (With or Without NAV) RAM 1500 2013-2017

(With 8.4" Display)
STEP #1: Open the cubby door below the climate control. With your hands begin the pull out on the bezel tha includes the climate control and air vents and surrounds the radio. Pull to release (2) clips, and continue to release (4) more clips. With hook tool assist to pull out the top of the bezel at the topside edge of the bezel above the air vents to release (2) more clips. Completely pull out the bezel and carefully set down on console with a towel or shop rag.

STEP #2: With the 9/32(7mm) socket driver, remove the (2) right side radio screws. Install the bottom of the InDash by PanaVise Mount onto the side of the radio.

STEP #3: Reinstall the radio and radio screws. While installing the radio s push the mount flush into the side of the radio for best fit. Reinstall the radio bezel starting from the opposite side with the mount on it. Be sure all the clips fasten securly.

STEP #4: Install the top part (75001) of the mount onto the bottom with the (2) supplied Acorn Nuts.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

I-75122-214

Page 1 of 2

ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Open Cubby door and pull from bottom of bezel under switches



Pull out bezel starting at the bottom, see complete bezel released





InDash Mount Installed w/8.4" Display Bottom part of InDash Mount installed w/Display



InDash Mount Installed w/Small Display



IIDASH PANAMSE®

MOUNTING LOCATION:

Right or Left side of display JP RL **TOOLS REQUIRED:**

Hook Tool Flat Bezel Tool 9/32"(7mm) Socket Driver **PARTS INCLUDED:** (1)s72064&(1)S71932(75001) 2 - (0) 8/32 Acorn Nuts

STEP#1: Remove console front tray

STEP#3: Remove rectangle trim from around the console cup holder/shifter/cubby/etc.(9clips)

STEP#5: Lift off rubber cover from cubby on top of radio/display Remove (2) T15 Torx screws.

STEP#7: Pull off the main bezel which includes the climate control, airvents, by pulling out from the bottom corners and using hook tool to assist and pulling top out.



In Dash mount bottom installed showing screw location and mount

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#:75122-214
MFG:JEEP / DODGE
MODELS & YEARS:
Grand Cherokee 2014-17
(With or Without NAV)
RAM 1500 2013-2017
(With 8.4" Display)













I-75122-214

Page 2 of 2

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP#2: Remove the (2) exposed Phillips head screws.

STEP#4: Open console door.Lift up on the console cover bezel that surrounds the cup holder/cubby/shifter/etc. Set aside

STEP#6: Remove rubber bottom from the cubby to right of climste control. Remove T15 Torx screw.

STEP#8:with 9/32 socket remove (2) right or left side display screws. Place InDash mount bottom over screw holes and replace screws



Mount bottom installed showing right side location with bezel in place



Finished install picture 01-16-18

