# IIDASH PANAMSE®

### **MOUNTING LOCATION:**

Above Radio/Display PU

# **TOOLS REQUIRED:**

Dash Tool - Plastic (Wide)

Phillips screwdriver

#### **PARTSINCLUDED:**

- (1)S71101714 Mount
- (1)S&7006 Mount Top
- (3)A #8x9/16" Needle Pt. Scrw

Cell Phone & Media Mount Installation Instructions PART#: **751101714** 

MFG: CHEVY/GMC MODELS & YEARS:

CHEVY-1500 Silverado 14-18

2500/3500HD Silverado 15-18

GMC -1500 Sierra 14-18 2500/3500HD Sierra 15-18

## NOTE: ANOTHER PART NUMBER AVAILBLE FOR THIS VEHICLE IS 751101614

STEP #1: With the Plastic Dash Tool, remove the bezel that surrounds the radio/climate control. Continue working your way around the bezel until all clips are released. Disconnect plug(s). Set the bezel aside.

STEP #2 Remove either 9/32(7mm) screw on the top of the radio cavity. Place the InDash by PanaVise Mount on top edge of the dash cavity. Be sure the edge of the mount is flat against the side. Re-Install the (1) factory screw, tighten, and (2) provided screws into the InDash Mount. Press the mount up to the edge of the dash cavity before tightening all the screws.



**I-751101714**Page 1 of 1

ADVISEMENT

Read instructions completely prior to

starting installation. All InDash Mounts

are designed so that after installation, phone

is facing normal driver position for left-

hand drive vehicles. This mount is not

designed to be used in foreign countries

with right-hand drive vehicles. Use extreme

care when working around the plastic

components on the dash. Excess force, can

cause breakage of the plastic components.

Bezel removed

STEP #3: Replace the bezel and install the top part (75006) with 5/16" wrench

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.





InDash bottom installed showing locations Right and Left





NORLOW WORLD

InDash installed showing locations Right and Left

06-28-18