INDASH PANAMSE®

MOUNTING LOCATION: Above Radio/Display JPRLU **TOOLS REQUIRED:**

Dash Tool 7mm Socket Driver **PARTS INCLUDED:**

(1) S71101614 Mount (3) A-#8x9/16" Needle Pt. Screw CELL PHONE & MEDIA MOUNT Installation Instructions

PART#: **751101614** MFG: CHEVY / GMC MODELS & YEARS: CHEVY-1500 Silverado 14-18 2500/3500HD Silverado 15-18 GMC - 1500 Sierra 14-18

2500/3500HD Sierra 15-18

STEP #1: With Dash tool remove the bezel around the Radio, may include switches. There are (10) total clips that hold it in place.

STEP #2: Remove (1) of the upper dash screws with 7mm socket driver.

STEP #3: Place the InDash Mount slot over the screw hole. Replace the screw while pushing the mount up to be flush with the dash. Thighten the screw.

STEP #4: Install 2 of the 3 supplied screws into the holes to the sides of the mount.

STEP #5: Replace the bezel.

751101614

Page 1 of 1

ADVISEMENT

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for lefthand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



InDash installed showing location

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDashinstalled showing Right mounting location

InDashinstalled showing **Right and Left** mounting location



InDashinstalled showing Left mounting location



