

MOUNTING LOCATION:

Right side of radio

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

TOOLS REQUIRED:

- Hook tool
- #2 Phillips screwdriver
- 8mm nut driver

PART#: **75137-999**
MFG: **TOYOTA**
MODELS & YEARS:
Tacoma Pickup 1998-2004

HARDWARE INCLUDED:

- (1) A - #8X9/16 Needle Point Screw

STEP #1 1998-2000 MODEL*: Remove the two sliding lever knobs on the climate control by pulling out. Also remove the two dial-type knobs by pulling straight out. Remove the climate control faceplate by inserting the hook tool through the sliding lever slots and carefully pulling out to release the plate clips from the left side. With your hands, release the rest of the clips; remove and set aside.

2001-04 MODEL INSTRUCTIONS: Remove ashtray by pushing down and pullout. Remove the power outlet cover that is behind the shifter console and below the ashtray by pushing on (2) pins with Phillips screwdriver and pulling out with fingers on each side. Lift out and disconnect power outlet wires. Remove (1) screw behind the ashtray.

STEP #2 * Locate three screws on the right side of the climate control; remove the middle screw that holds the bezel surrounding the climate control and radio. On the left side of the climate control, remove the upper left side screw which points up at an angle toward the front. Set the screws aside. Open and remove the ashtray by pressing on the metal tab and pulling out. Set ashtray aside. Remove one screw far in the back of the ashtray cavity and set aside.

2001 MODEL INSTRUCTIONS: Unscrew the (2) phillips screws above the climate control. Pull the bezel that surrounds the Ashtray / Radio / climate control / air vents, by starting from the bottom under the ashtray cavity and working your way to the vents. There are (6) clips total.

2002-2004 MODEL INSTRUCTIONS: With hook tool, remove climate control face plate and knobs, set aside. Remove (2) Phillips screws at the top left and right side of the climate control.

STEP #3 * Between the console and the ashtray is a bezel with two power outlets integrated into it. This bezel must be released from the clips in order to remove the bezel surrounding the radio and climate control, but DO NOT remove completely. Locate two plastic retainers, one on each side of the bezel (one on the passenger side, and one on the driver's side) and release these two retainers by pressing on the center of the retainers with a Phillips screwdriver until you hear or feel a click. Pull on the bezel to release the retainers and set them aside. Once the retainers have been removed, pull the bezel to release three clips. DO NOT remove completely, just let it rest in place.

2001-04 MODEL INSTRUCTIONS: Unscrew right side radio screw and install mount over it. Install the (1) supplied screw with Phillips screwdriver into hole on InDash by PanaVise. Replace screw, bezel, power outlet, and climate control cover and knobs in reverse order.

This completes installation of the 2001-04 model. See page 2 for the completion of 98-2000 models.

(cont. on pg 2)

05-13-04



- STEP #4 Remove the bezel that surrounds the climate control and radio starting from the top and pulling to release one clip on each upper corner of the bezel. Continue releasing the bezel by pulling from the middle of the bezel to release two more clips. Pull from the bottom of the bezel to release bottom clips. Once the entire bezel has been released, pull on the bezel with the two power outlets, just enough for the top bezel to clear from the bottom enabling you to push the top bezel toward the left side allowing you room to work on the right side of the radio. DO NOT disconnect wires.
- STEP #5 Remove the upper 8mm Hex screw on the right side that holds the radio. Place the InDash Mount over the screw hole and guide pin and install the screw back into place and tighten. Install the (1) supplied screw with Phillips screwdriver into hole on InDash by PanaVise.
- STEP #6 Reassemble dash in reverse order. Attach phone holder to InDash Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



InDash mounted showing screw location



Finished Installation Picture