

INDASH by PANAVISE®

75102-109

Page 1 of 1

MOUNTING LOCATION:

Right side of radio JR

TOOLS REQUIRED:

Dash Tool, Hook Tool

8mm Socket Driver

HARDWARE INCLUDED:

75001 TOP W/(2)-O- 8/32" Acorn Nuts

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS**

PART#: 75102-109

MFG: AUDI

MODELS & YEARS:

A4 09-16, S4 10-16

A5 08-16, S5 08-16

Allroad 13-16

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash Tool remove the air vents by prying under the display bezel and pulling on the side of the air vents with the hook tool. Pulling down on air vents to release. Set air vents aside.

STEP #2: With 8mm socket driver remove the bolt in the lower right of cavity that holds the radio in place. Place bottom of InDash by PanaVise Mount #75102-109 over screw hole and replace bolt.

STEP #3: Replace the air vents. Install the top piece #75001 onto the bottom part of the mount with the (2) 5/16" acorn nuts.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Bottom piece installed showing mounting location



InDash installed showing location



01-20-16

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2016 PanaVise Products, Inc.