

INDASH by PANAVISE®

751072614

Page 1 of 1

MOUNTING LOCATION:

Right side of radio cavity KR

TOOLS REQUIRED:

Dash Tool,
T20 Torx Driver
Phillips Screwdriver

PARTS INCLUDED:

(1)S7-2081 Mount
(3)A-#8x9/16 Needle Pt.Screw

MOBILE DEVICE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 751072614

MFG: FORD

MODELS & YEARS:

Transit Connect 2014-2016

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash tool remove the bezel cover above the Radio/Display, that includes the air vents. Start by lifting up on the front edge of the Cover, pulling towards you releasing (4) clips, while lifting up to release (2) cleats at the back of the bezel. Set aside.

STEP #2: Remove the (2) T20 Torx mounting screws. Pull out on the bezel around the radio starting in one corner and working your way around the vents and controls. Releasing (4) clips, and (4) springs on the sides. Set aside. Unplug only if needed.

STEP #3: Place the Indash Mount on the lower right side of the radio cavity, see location in picture below. Be sure the joggle and edges of the mounting arm align as pictured, then install the (3) screws supplied

STEP #4: .Replace the radio and screws. Install the top mounting piece.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Top Bezel Removal



InDash installed lower location



InDash installed lower location



(2) Torx Screw Removal



InDash installed upper location



InDash installed upper location



01-20-16