IIDASH ParaMise®

MOUNTING LOCATION:

Right side of radio

TOOLS REQUIRED:

10mm Socket/driver Hook tool #2 Phillips screwdriver

HARDWARE INCLUDED:

None

Cell Phone & Media Mount Installation Instructions

PART#: **75137-200** MFG: **TOYOTA** MODELS & YEARS: **Celica GT 2000-2005** I-75137-200

Page 1 of 1

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1 With hook tool pull up bezel that surrounds the shifter and includes the ashtray and lighter. You need to put on emergency brake, turn on ignition, DO NOT START, and shift into neutral. Pull up bezel to release (4) clips. Disconnect wiring and set aside.
- STEP #2 Remove (2) screws below the climate control, pull off all turn knobs and slide knob. Remove (2) screws from behind the climate control knobs. Lift up from the bottom of bezel, tilt up by moving slightly side to side to release clip from top of bezel at the point above the clock. Disconnect wire and set aside.
- STEP #3 With 10mm nut driver remove (4) bolts holding the radio on. Install the InDash Mount under the upper right screw bracket, and over guide pin. Screw in all (4) screws for radio. Reinstall bezel with clock and (2) screws below climate control, shifter bezel. Install (2) screws on climate control and all knobs. Attach the phone holder to your InDash Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



InDash Mount in place showing installation



Finished Install Picture



