

INDASH by PANAVISE®

I-75107-397

Page 1 of 1

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

MOUNTING LOCATION:

Below climate control
between lighter & cup holder

TOOLS REQUIRED:

9/32 nut driver
Phillips screwdriver
Hook tool
Ford radio removal tool

HARDWARE INCLUDED:

(2) A - #8X9/16 Needle Point Screw

PART#: **75107-397**
MFG: **FORD**
MODELS & YEARS:
F150 97-2003, F250 (LD) 97-2001
(AT only) New body style
F150 SuperCrew (AT) 2001-03
F150 Super Cab (AT) 2001-03
Expedition 97-02, F-150 Heritage 2004
(ALL: W/ Manual Climate Control)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1 Remove the bezel which surrounds the climate control and radio by pulling it from each upper corner of radio with hook tool, then pull from each lower corner of the climate control.
- STEP #2 Disconnect the electronic 4X4 switch located on the left side of bezel (if equipped). DO NOT DISCONNECT the air bag switch on the right side of bezel. Swing/pivot the bezel toward the right and set it on top of the dash to allow room for installation.
- STEP #3 Open the cup holder. Using the Ford radio removal tools, remove the radio (DO NOT DISCONNECT) and set it on top of the cup holder. Remove four screws that hold the climate control in place. Carefully pull the climate control out as much as possible without overstretching the wires.
- STEP #4 Take the InDash Mount and with the Part Number readable from left to right, slide it under the climate control on the bottom flat surface of the climate control's cavity. Place the left hole of the InDash Mount (horizontal plane) over the lower left mounting hole of the climate control; and install that screw to hold the Mount. Push the InDash Mount in so the bend will rest tight against the dash and install the two screws that have been provided.
- STEP #5 Remove the screw from the lower left mounting hole of the climate control and reposition the climate control back into place and secure with the four screws. Reinstall the radio, reconnect the 4X4 switch and push the bezel back into place; lock securely by the four clips.
- STEP #6 Attach phone holder to InDash Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Finished Install Picture



08-20-04