

# INDASH by PANAVISE®

I-75107-202

Page 1 of 1

## MOUNTING LOCATION:

Right side of air vents and climate control (VC R)

## TOOLS REQUIRED:

Hook tool  
Phillips screwdriver (Power)  
Clean shop cloth

## HARDWARE INCLUDED:

(3) A - #8X9/16 Needle Point Screw

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75107-202**  
MFG: **FORD/MERCURY**  
MODELS & YEARS:  
**FORD Explorer 2002-05**  
**MERCURY Mountaineer 2002-05**

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP#1: With hook tool insert it between the bezel and dash below climate control, close to the buttons, and pull to unsnap. Continue to unsnap bezel along the sides by the crease in the dash, and pull out from the top of the bezel, releasing the whole bezel completely.

STEP#2: Disconnect the connector for the 4x4 switches (if equipped). Place the clean shop cloth over the bottom of the dash cavity to protect it from the clips on the bottom of the bezel.

STEP#3: Place the InDash by PanaVise Mount along the right side of the bezel, to the upper right of the climate control. (See picture).

STEP#4: Push the mount flush up against the dash in a location that the mount is flush with all (3) surfaces it touches. Screw in the first self drilling screw in the top on of the (2) holes on the side of the mount. Not the one facing you. Repeat on the bottom hole, and finally on the hole facing you, always making sure of the flush fit.

STEP#5: Plug in the 4x4 connector, and replace the bezel in reverse order.

INSTALLATION IS COMPLETE.

ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Area of mounting



Mounting location



08-04-04