

MOUNTING LOCATION:

Below climate control
(between lighter & cup holder)

TOOLS REQUIRED:

Phillips screwdriver
Hook tool
Ford radio removal tools
3/32 drill bit and drill

HARDWARE INCLUDED:

(3) A - #8X9/16 Needle Point Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: **75107-399**

MFG: **FORD / LINCOLN**

MODELS & YEARS:

**FORD Expedition 97-02, F-150 Heritage 2004
F150 97-2003**

LINCOLN Navigator 00-02, Blackwood 2002

(All With Auto Climate Control & AT)

(Will partially block GPS, if equipped)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDashMounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1** Remove the bezel which surrounds the climate control and radio, by pulling from each upper corner of the radio (using the hook tool); then pull from each lower corner of the climate control.
- STEP #2** Disconnect the electronic 4x4 switch located on the left side of bezel (if equipped). **DO NOT DISCONNECT** the air bag switch on the right side of the bezel (except on the Navigator 2000-01). Swing/pivot the bezel toward the right and set it on top of the dash to allow room for installation.
- STEP #3** Open the cup holder. With the Ford radio removal tool, remove the radio (**DO NOT DISCONNECT**) and set it on top of the cup holder. Remove four screws that hold the climate control in place. Carefully pull the climate control out as much as possible without over stretching the wires.
- STEP #4** Take the InDash Mount and place it on the middle of the bottom flat surface of the climate control cavity (part number of the Mount should be readable from left to right). Mark three holes then remove the Mount and drill three 3/32 pilot holes. Place the InDash Mount over the holes and secure with the three needle point screws provided.
- STEP #5** Position the climate control back into place and secure with the four screws. Reinstall the radio. Reconnect the 4x4 switch and push the bezel back into place, locking securely with the four clips.
- STEP #6** Attach phone holder to InDash Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Finished Install Picture
(Showing rear climate control)



08-04-04