

INDASH by PANAVISE®

I-75110-795

Page 1 of 1

MOUNTING LOCATION:

Upper left corner of glove box

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS**

TOOLS REQUIRED:

Phillips screwdriver
7mm nut driver

PART#: **75110-795**
MFG: **CHEVROLET**
MODELS & YEARS:
Cavalier 1995-2005

HARDWARE INCLUDED:

(2) A - #8X9/16 Needle Point Screw

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1 Open the glove box and remove the three screws located along the top of the glove box. These screws hold the top dash panel. Lift the panel up just enough to expose a step on the upper left corner of the glove box. Place an object (could use a screwdriver handle) between the panel and the bezel (above the air vents) to hold the panel out while working on mounting the InDash Mount.
- STEP #2 Attach phone holder to InDash Mount. If mounting a PortaGrip phone holder make sure to adjust the holder to the size of the phone prior to installation.
- STEP #3 Place the InDash Mount on the step on the upper left corner of the glove box and secure it with the two self-drilling screws that have been supplied.
- STEP #4 Reposition the top dash panel and reinstall the three screws.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Finished Install Picture



07-12-04