

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

MOUNTING LOCATION:

Left or Right Side of Radio

TOOLS REQUIRED:

9/32 nut driver
Hook tool

HARDWARE INCLUDED:

(1)S7-1561 Mount

PART#: 75122-201

MFG: JEEP

MODELS & YEARS:

**Grand Cherokee Laredo 1999-2004,
Grand Cherokee Limited 1999-2004,
Grand Cherokee Overland 2004,
Grand Cherokee Special Edition 2004
(With or Without Factory Nav)**

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With the hook tool remove the bezel that surrounds the radio by inserting the hook tool between the bezel and the dash. Release (2) spring clips located at the top of the bezel, and pull from the right and left side of the air vents below the radio to release (2) more spring clips. Once all (4) spring clips have been released set bezel aside. Remove (2) screws located on the *left or right* side of the radio, depending on which side of the radio you choose to place the mount.

STEP #2 Attach phone holder to InDash Mount. (Either to the left side of radio, part number and logo will be right side up. Or to the right side of radio, part number and logo will be upside down) If using a PortaGrip phone holder, adjust to size of phone prior to mounting. Pull the left side of the radio just enough to slide the InDash under the radio, align holes, and push radio back in place. Reinstall the (2) screws.

STEP #3 Reinstall bezel back into place.

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Install Location Screws



Left Side of Radio Mounting



Right Side of Radio Mounting



05-19-15