

# INDASH by PANAVISE®

**I-75140-101**

Page 1 of 1

**\*\* ADVISEMENT \*\***

**MOUNTING LOCATION:**

Right side of dash panel

**TOOLS REQUIRED:**

T-25 Torx driver

**HARDWARE INCLUDED:**

None

**CELL PHONE & MEDIA MOUNT**

**INSTALLATION INSTRUCTIONS**

**PART#: 75140-101**

**MFG: PETERBILT**

**MODELS & YEARS:**

**Conventional Cab, 2001-2005 Incl.**

**Model No.'s (357, 378, 379, 385,387)**

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1:** With T-25 Torx driver, remove (6) screws on dash panel with climate control and switches. Lift up panel just enough to place InDash by PanaVise behind panel and over the (2) far right side screws.

**STEP #2:** Install the (2) screws that hold the InDash by PanaVise in place. Replace the (4) remaining screws that hold this panel in and tighten all.

**INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.**



Finished Installation Picture



06-18-04