

INDASH by PANAVISE®

751101619

Page 1 of 1

MOUNTING LOCATION:

Upper Left off Radio/Display

TOOLS REQUIRED:

Dash Tool, Hook Tool
T20 Torx Driver

PARTS INCLUDED:

- (1) 751101619 Lower Mount
- (1) 75006 Upper Mount
- (2) 8-32 Acorn nuts

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 751101619

MFG: CHEVY/GMC

MODELS & YEARS:

CHEVY- 1500 Silverado 19-20

2500/3500HD Silverado 20

GMC - 1500 Sierra 19-20

2500/3500HD Sierra 20

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash tool remove the bezel around the Radio, starting from the lower corners and working your way around the bezel. there are 9 clips, see image below for clip location.

STEP #2: Remove (4) screws that secure the bezel/cluster that surrounds the screen and climate control as shown on picture.

STEP #3: With hands, apply upward pressure to the bezel that surrounds the screen and carefully pull just enough to release upper clips and to be able to slide the InDash mount under the upper left screw hole and locating pin.

STEP #4: Place the lower (751101619) InDash Mount center hole under the bezel and on locating pin. Once the Indash Mount is in place, push bezel/cluster back into place and re install the 4 screws.

STEP #5: Replace the bezel removed on step #1

STEP #6: Install the Upper InDash Mount (75006) to the Lower InDash Mount with accorn nuts provided.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Screws to be removed



Bezel clip locations



Mounting Location



InDash complete assembly



01-19-16