

Overview

Designed to provide maximum coverage throughout indoor areas, the SureCall panel antenna is a high gain inside antenna that propagates signals in a 120° beamwidth.

The ultra wide band antenna transmits and receives signals directionally and is designed to cover 2G/3G/4G/5G and WLAN systems for Cellular, PCS, AWS and LTE frequencies.

- » N-Female connector (50 Ω)
- » 5.5/6/8dBi Max Gain
- » Wide band: 2G, 3G, 4G & 5G (617 2700 MHz)
- » Wall-mounted indoor antenna




Specifications

Frequency	617-697 / 698-960 / 1710-2700 MHz
Beamwidth	H:110° E:70° / H:90° E:80°/ H:65° E:55°
Max Gain	5.5 / 6 / 8 dBi
VSWR	<2
Input Impedance	50 Ω
Polarization Type	Vertical
Max Power	50W
Radiation Pattern	Directional
Connector Type	N-Female
Mount Type	Wall-mounted Installation
Dimensions	8.2 x 7 x 1.78 in (208 x 178 x 45 mm)
Weight	2.2 lbs (1000 g)
Cover Material	ABS
Operating Temp.	-22°F to +140°F
Operating Humidity	5% ~ 95%
	-

Installation

- 1. Choose the the ideal location for mounting antenna on a vertical surface. Ideal height off the floor should match the approximate height of regular cell phone use.
- 2. Using plate, mark position of desired screw placement with pencil or marker.
- 3. Screw mounting plate into place with the slide panel protruding towards you.
- 4. Slide antenna securely onto mounting plate.
- 5. Connect antenna with SC-400 cable that leads to your booster port marked INSIDE.

Note: Wherever possible, it is recommended to provide maximum separation between outside and inside antennas. Remember to face the panel antenna away from the outside antenna.



Compatibility

Booster Compatibility: All SureCall 2G-5G home and industrial in-building signal boosters Cable Compatibility: Low coax cables with N Male on either end (SC-400, SC-240, etc.) Accessory Compatibility: SureCall Couplers and Splitters